



1. Set Protocol to "Binary"

2. Set CTRL-D to "No"

3. Set Available Tray, Resolution and Memory to values appropriate for printer's configuration.

4. After configuring printer, click "OK" to finish the Installation Wizard.